

Mini User Manual for Hockey

The unit has 6 buttons. **Note that most actions happen when you press and then immediately take your finger off the button.** Do not hold a button down unless you are trying to correct a mistake.

START Starts the clock running. If you make a mistake, you can hold down this button for 3 seconds to subtract an extra 10 seconds from the time. **Before** the start of a match, holding down this button for 3 seconds will reduce the start time by 5 minutes so that any length of period is possible; 35,30,25, etc down to 5 minutes. Holding the button at 5 minutes resets it back to a start time of 35:00. (For times such as 7½ minutes, set the start time at 5 minutes then hold the STOP button to go back up to 7½.)

STOP Stops the clock. If you make a mistake, you can hold down this button for 3 seconds to add 10 seconds to the time.

**← +
SCORE** Pressing once will add one to the left hand score (as you look at the scoreboard). If you make a mistake, you can hold down this button for 3 seconds to reduce the score by one (hold the button down until the score changes).

**+ →
SCORE** Pressing once will add one to the right hand score (as you look at the scoreboard). If you make a mistake, you can hold down this button for 3 seconds to reduce the score by one (hold the button down until the score changes).

**NEXT
PERIOD** This button only works when the clock is stopped. Pressing the button will set the scoreboard for the next period. The time will be reset back to 35:00 minutes (or whatever the start time is set to). After 5 minutes of the end of the first half, the bell will optionally sound to denote the end of time out.

RESET This button only works when the clock is stopped. Pressing the reset button will set up the scoreboard for the next match. The time will be reset to 35:00 minutes (or whatever the start time is set to) and both scores set to zero. If you make a mistake, hold down this button for about 3 seconds. In this case, the scoreboard will revert to all the values before you pressed the button.

Holding down the STOP button and pressing the RIGHT SCORE button will display the actual time in hours and minutes. You can only select this at the end of a match when the clock is reset. You can correct the hours by pressing the left score button. The right score button corrects the minutes. To return to normal scoreboard operation hold down the STOP button and pressing the RIGHT SCORE button again.

Holding down the STOP button and pressing the RESET button will sound the horn whilst you hold the buttons. This only works before the beginning of the match when the time is 35:00 minutes. The use of this is to hurry on the players for the next match.

Sporting Designs Ltd, One Barkers Field, Long Clawson, Leicestershire LE14 4PL, UK.
www.SportingDesigns.co.uk mail@SportingDesigns.co.uk
Tel 07860 303 217 Fax 0870 210 1008